



ATTACHMENT DETAIL

1. SILICONE TO BE PLACED ON THE BLIND STOP SUCH THAT IT ESTABLISHES A SEAL BETWEEN THE NAILING FLANGE AND BLIND STOP.
2. NORMAL INSTALLATION WILL INCLUDE FACTORY, PRE-DRILLED HOLES ON THE HEAD, LEFT AND RIGHT JAMB.
3. FACTORY SUPPLIED ATTACHMENT SCREWS (#6A X 1/2" PAN HEAD 410 STAINLESS STEEL) SHOULD BE USED TO ATTACH THE FRAME TO THE BLIND STOP THROUGH EACH OF THE ATTACHMENT HOLES.

QUANTAPANEL®

QP704-DH INSULATING GLASS SYSTEM
DETAIL SHEET 2 - INSTALLED

NOTES:

DATE
08/04/2020

SCALE
1" = 5'

DRAWN BY
R.A.S.